



TIG200VP

DC INVERTER WELDER

OPERATORS MANUAL



IMPORTANT

Please carefully read and understand this instruction manual before operating this equipment.

CONTENTS	PAGE
Safety	3-4
Caution, Maintenance and Trouble Shooting	5
Technical Data, Product Information	6
Machine Layout Descriptions	7
Front Panel Operation - Functions	8-9
Installation & Operation for MMA (stick) Welding	10-11
MMA (Stick) Welding	12-13
Set up & Operation for DC TIG Welding	14-15
DC TIG Welding - HF Ignition	16
DC PULSE TIG Welding	17
Set up & Operation for DC PULSE TIG Welding	18
TIG Welding Fusion and Filler Wire Technique	19
Remote Amp Controls	20
Tungsten Electrodes - Tungsten Preparation	21-22
TIG Torch Parts Breakdown	23-25
Trouble Shooting Guide - MMA (Stick) Welding	26
Trouble Shooting Guide - TIG Welding	27-28
Warranty Policy	30-31

Thank you for your purchase of your Xcel-Arc VIPER welding machine.

We are proud of our range of welding equipment that has a proven track record of innovation, performance and reliability. Our product range represents the latest developments in inverter technology put together by our professional team of highly skilled engineers. The expertise gained from our long involvement with inverter technology has proven to be invaluable towards the evolution and future development of our equipment range. This experience gives us the inside knowledge on what the arc characteristics, performance and interface between man and machine should be. Within our team are specialist welders that have a proven history of welding knowledge and expertise, giving vital input towards ensuring that our machines deliver control and performance to the utmost professional level. We employ an expert team of professional sales, marketing and technical personnel that provide us with market trends, market feedback and customer comments and requirements. Secondly they provide a customer support service that is second to none, thus ensuring our customers have confidence that they will be well satisfied both now and in the future.

Xcel-Arc VIPER welders are manufactured and compliant with -
ANSI/IEC 60974-1, AS/NZ60974-1 guaranteeing you electrical safety and performance.

WARRANTY

- 1 Year from date of purchase.
- Esseti NZ Ltd Ltd warranties all goods as specified by the manufacturer of those goods.
- This Warranty does not cover freight or goods that have been interfered with.
- All goods in question must be repaired by an authorised repair agent as appointed by this company.
- Warranty does not cover abuse, mis-use, accident, theft, general wear and tear.
- New product will not be supplied unless Esseti NZ Ltd has inspected product returned for warranty and agree's to replace product.
- Product will only be replaced if repair is not possible

SAFETY

Welding and cutting equipment can be dangerous to both the operator and people in or near the surrounding working area, if the equipment is not correctly operated. Equipment must only be used under the strict and comprehensive observance of all relevant safety regulations. Read and understand this instruction manual carefully before the installation and operation of this equipment.

Machine Operating Safety

- Do not switch the function modes while the machine is operating. Switching of the function modes during welding can damage the machine. Damage caused in this manner will not be covered under warranty.
- Disconnect the electrode-holder cable from the machine before switching on the machine, to avoid arcing should the electrode be in contact with the work piece.
- Operators should be trained and or qualified.



Electric shock: It can kill. Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and internal machine circuits are also live when power is on. In Mig/Mag welding, the wire, drive rollers, wire feed housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is dangerous.

- Connect the primary input cable according to Australian and New Zealand standards and regulations.
- Avoid all contact with live electrical parts of the welding circuit, electrodes and wires with bare hands. The operator must wear dry welding gloves while he/she performs the welding task.
- The operator should keep the work piece insulated from himself/herself.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cable for wear and tear, replace the cable immediately if damaged, bare wiring is dangerous and can kill.
- Do not use damaged, under sized, or badly joined cables.
- Do not drape cables over your body.



Fumes and gases are dangerous. Smoke and gas generated whilst welding or cutting can be harmful to people's health. Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Do not breathe the smoke and gas generated whilst welding or cutting, keep your head out of the fumes
- Keep the working area well ventilated, use fume extraction or ventilation to remove welding fumes and gases.
- In confined or heavy fume environments always wear an approved air-supplied respirator. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near de-greasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapours to form highly toxic and irritating gases.
- Materials such as galvanized, lead, or cadmium plated steel, containing elements that can give off toxic fumes when welded. Do not weld these materials unless the area is very well ventilated, and or wearing an air supplied respirator.



Arc rays: harmful to people's eyes and skin. Arc rays from the welding process produce intense visible and invisible ultraviolet and infrared rays that can burn eyes and skin.

- Always wear a welding helmet with correct shade of filter lens and suitable protective clothing including welding gloves whilst the welding operation is performed.
- Measures should be taken to protect people in or near the surrounding working area. Use protective screens or barriers to protect others from flash, glare and sparks; warn others not to watch the arc.



Fire hazard. Welding on closed containers, such as tanks, drums, or pipes, can cause them to explode. Flying sparks from the welding arc, hot work piece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- The welding sparks may cause fire, therefore remove any flammable materials away from the working area, at least 12m from the welding arc. Cover flammable materials and containers with approved covers if unable to be moved from the welding area.
- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to the required Safety Standards to insure that flammable or toxic vapors and substances are totally removed, these can cause an explosion even though the vessel has been “cleaned”. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Do not weld where the atmosphere may contain flammable dust, gas, or liquid vapours (such as petrol)
- Have a fire extinguisher nearby and know how to use it. Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.



Gas Cylinders. Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Because gas cylinders are normally part of the welding process, be sure to treat them carefully. CYLINDERS can explode if damaged.

- Protect gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Insure cylinders are held secure and upright to prevent tipping or falling over.
- Never allow the welding electrode or earth clamp to touch the gas cylinder, do not drape welding cables over the cylinder.
- Never weld on a pressurised gas cylinder, it will explode and kill you.
- Open the cylinder valve slowly and turn your face away from the cylinder outlet valve and gas regulator.



Gas build up. The build up of gas can causes a toxic environment, deplete the oxygen content in the air resulting in death or injury. Many gases use in welding are invisible and odourless.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



Electronic magnetic fields. MAGNETIC FIELDS can affect Implanted Medical Devices.

- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near any electric welding, cutting or heating operation.



Noise can damage hearing. Noise from some processes or equipment can damage hearing. Wear approved ear protection if noise level is high.



Hot parts. Items being welded generate and hold high heat and can cause severe burns. Do not touch hot parts with bare hands. Allow a cooling period before working on the welding gun. Use insulated welding gloves and clothing to handle hot parts and prevent burns.

CAUTION

1. Working Environment.

- 1.1 The environment in which this welding equipment is installed must be free of grinding dust, corrosive chemicals, flammable gas or materials etc, and at no more than maximum of 80% humidity.
- 1.2 When using the machine outdoors protect the machine from direct sun light, rain water and snow etc; the temperature of working environment should be maintained within -10°C to +40°C.
- 1.3 Keep this equipment 30cm distant from the wall.
- 1.4 Ensure the working environment is well ventilated.

2. Safety Tips.

2.1 Ventilation

This equipment is small-sized, compact in structure, and of excellent performance in amperage output. The fan is used to dissipate heat generated by this equipment during the welding operation.

Important: Maintain good ventilation of the louvers of this equipment. The minimum distance between this equipment and any other objects in or near the working area should be 30 cm. Good ventilation is of critical importance for the normal performance and service life of this equipment.

2.2 Thermal Overload protection.

Should the machine be used to an excessive level, or in high temperature environment, poorly ventilated area or if the fan malfunctions the Thermal Overload Switch will be activated and the machine will cease to operate. Under this circumstance, leave the machine switched on to keep the built-in fan working to bring down the temperature inside the equipment. The machine will be ready for use again when the internal temperature reaches safe level.

2.3 Over-Voltage Supply

Regarding the power supply voltage range of the machine, please refer to “Main parameter” table. This equipment is of automatic voltage compensation, which enables the maintaining of the voltage range within the given range. In case that the voltage of input power supply amperage exceeds the stipulated value, it is possible to cause damage to the components of this equipment. Please ensure your primary power supply is correct.

- 2.4 Do not come into contact with the output terminals while the machine is in operation. An electric shock may possibly occur.

MAINTENANCE

Exposure to extremely dusty, damp, or corrosive air is damaging to the welding machine. In order to prevent any possible failure or fault of this welding equipment, clean the dust at regular intervals with clean and dry compressed air of required pressure.

Please note that: lack of maintenance can result in the cancellation of the guarantee; the guarantee of this welding equipment will be void if the machine has been modified, attempt to take apart the machine or open the factory-made sealing of the machine without the consent of an authorized representative of the manufacturer.

TROUBLE SHOOTING

Caution: Only qualified technicians are authorized to undertake the repair of this welding equipment.

For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed in this manual.

VIPER TIG200VP

TIG/MMA - 200 Amp DC Inverter Welder

Welds: Steels, Stainless, Cast Iron, Bronze, Copper



VIPER TIG200VP

Entry Level Inverter Welder

230V Single Phase DC Welder HF TIG/MMA

200 Amp DC-TIG with Pulse, 160 Amp MMA



Features

- Modern IGBT inverter technology
- Simple to use analogue controls with Digital Amp Meter
- DC TIG (DC tungsten inert gas welding)
 - HF Arc Ignition (prevents tungsten inclusion & tungsten damage)
 - Adjustable Pulse Frequency 0.5 - 200Hz
 - Adjustable Peak Current
 - Auto Base Current and pre-set Pulse Width
 - 2/4T Trigger Control
 - Down Slope Adjustment
 - Post Gas Flow Adjustment
 - Remote Torch Amp Control
- MMA (stick electrode)
 - Arc Ignition Adjustment
 - Adjustable Arc Force (boosts current to prevent electrode extinguishing)
- Thermal Overload Protection
- Generator compatible (recommend 8.0KVA minimum)

Technical Data

Power Supply / Phases (V-Ph)	240V - 1 ±15%
Rated Input Power (KVA)	8.0
iMax	34.0
ieff (as per AS/NZ60974-1)	15.0
Output Current Range TIG	10-200A/18.0V
Output Current Range MMA	10-160A/27.2V
No-Load Voltage (V)	75
Duty Cycle @ 40°C as per AS/NZ60974	30%@200Amps TIG 20%@160 Amps MMA
Duty Cycle @ 25°C	60%@200Amps TIG 50%@160 Amps MMA
Protection Class	IP21S
Insulation Class	F
Size (mm)	420 x 160 x 330
Weight (kg)	7.5kg
Warranty	1 year machine only
Certification Approval	AS/NZ60974-1

VIPER TIG200P OPTIONAL ACCESSORIES



Remote Foot Control
Part No. XA-RFC-1



Twin Flowmeter Regulator
Part No. XG-ARLFM25TW

Overview

The VIPER TIG200P is an inverter-based DC Tig welding machine with HF arc ignition and pulse capability. Produced using the latest in IGBT technology this low cost and portable machine is reliable, robust and stacked with all the functions you expect from a professional DC TIG welder. The HF arc ignition provides pre gas and instant arc ignition with the press of the torch switch leaving no tungsten inclusion and no contamination of the tungsten electrode. The Down Slope, Post Gas functions combined with the 2/4T trigger function allows you to control the start and finish of the weld process at a professional level. The addition of adjustable pulse frequency 0.2-200Hz gives you the added capability to control the heat input into the work, control penetration and help control distortion. Torch Remote Control Interface provides remote amperage control from the torch in both static and live welding modes. The remote control receptacle provides optional connection of foot control. Combining the functions of the VIPER 200P ensures comprehensive control of the welding parameters when welding all DC weldable materials giving a remarkably smooth arc producing high quality TIG welds. The DC MMA welding capability delivers a smooth and stable arc allowing easy welding with electrodes obtaining high quality welds including cast Iron, stainless and low hydrogen. The VIPER TIG200P is a professional machine that is suitable for multiple applications; stainless steel fabrication, light industrial use, sitewelding, repair and maintenance applications.

Built to our specification and manufactured in compliance to AS/NZ60974.1

Product Code: XA-ARC140V

Standard package includes: VIPER ARC140 Machine, Earth Lead & Arc Lead 16mm x 2.5m


Front Machine Layout Description




Rear Machine Layout Description





Front Panel Functions




1. Mode Selector - Enables selection of required welding mode - MMA - DC TIG



MMA: Select by pushing the selector button to cycle through to illuminate the  icon.




DC Tig: Select by pushing the selector button to cycle through to illuminate the  icon.

2. Adjustment Knobs - provides adjustment of the welding parameters.




The **Knob** is used to set the value of the parameters required. Turning the encoder will adjust the value shown in the digital display screen.

3. Torch Switch Mode Selector - Controls the on/off cycle of the machine using the torch switch.




2T: Select the 2T icon using the selector pad. 2T uses 2 actions of the torch switch (refer to page 10 for instruction of 2T function)




4T: Select the 4T icon using the selector pad. 4T uses 4 actions of the torch switch (refer to page 11 for instruction of 4T function)

4. Pulse Selector - Enables selection of PULSE or NON PULSE mode in TIG welding mode




NO PULSE: Push the pad to select the  icon.




PULSE: Push the pad to select the  icon.



4. Remote Selector - Enables activation of a remote control is when it is connected to the machine



PANEL: Push the pad to select the PANEL icon. This provides adjustment of the welding amps by using the adjustment knob on the machine.



REMOTE: Push the pad to select the REMOTE icon. This provides adjustment of the welding amps by using the remote control connected to the machine

MMA (Stick) Control Knobs



MMA Amperage: Turning the knob adjusts the AMPS (welding current) output from 10-160 Amps - displayed by the digital meter.

ARC Force Control



MMA Arc Force: Turning the knob adjusts the ARC FORCE from 0-100 displayed by the digital meter. The arc force control lets you adjust the force of the arc from a soft buttery arc to a more penetrating, digging type of arc. Higher Arc Force is more suited to Cellulose and Low Hydrogen type electrodes where a forceful arc characteristic is preferred to maintain the arc and better control penetration. Lower Arc Force is better suited to Hardfacing and Cast Iron electrodes where a soft buttery arc is preferred to prevent the electrode material diluting too much with the base metal.

TIG CONTROL KNOBS

Amperage



TIG Amperage: Turning the knob adjusts the AMPS (welding current) output from 10-160 Amps - displayed by the digital meter.

TIG Down Slope Control



TIG Down Slope: Turning the knob sets the transition time from welding amps to minimum amps when finishing the weld. The value selected shows on the digital display and can be set from 0-5 seconds. It is the amount of time taken for the welding to drop down to minimum amps

TIG Post Gas Control



TIG Post Gas: Turning the knob adjusts the amount of time that the gas continues to flow after the arc has extinguished. The value selected shows on the digital display and can be set from 0-10 seconds.

TIG Pulse Frequency Control



TIG Pulse Frequency: Turning the knob adjusts the amount of pulses per second that the welding current switches from the set welding amps to base amps. (The base amperage is pre-set at 40% of the set welding amps.) The pulse frequency value selected shows on the digital display and can be set from 0-200 pulses per second (Hz).

- (1) **Connection of Output Cables:** Various electrodes require a different polarity for optimum results refer to the electrode manufacturers information for the correct polarity. Most GP electrodes are Electrode connected to \ominus output socket, Earth Connected to the \oplus output socket
- (2) Connect the machine to the power supply and switch on using the on/off switch on the back panel.
- (3) Set the welding current relevant to the electrode type and size being used as recommended by the electrode manufacturer.
- (4) Place the electrode into the electrode holder and clamp tight
- (5) Strike the electrode on the work to create the arc and hold the electrode steady to maintain the arc
- (6) Hold the electrode slightly above the work piece to maintain the arc while travelling at an even speed to create and even weld deposition
- (7) To finish the weld, break the arc by quickly snapping the electrode away from the work piece.
- (8) Wait for the weld to cool and carefully chip away the slag to reveal the weld metal underneath



(3) Select DC MMA Function. Push the **DC** button until the **DC** icon glows red.



(4) Set the weld amperage by rotating the **Amps Knob**. Set the amperage according to the electrode type and size being used as recommended by the electrode manufacturer. The set amperage will show in the **Digital Display**.



(5) Set the arc force by rotating the **Arc Force Knob**. Set the arc force according to the electrode type being used. Higher Arc Force is more suited to Cellulose and Low Hydrogen type electrodes where a forceful arc characteristic is preferred to maintain the arc and better control penetration. Lower Arc Force is better suited to Hardfacing and Cast Iron electrodes where a soft buttery arc is preferred to prevent the electrode material diluting too much with the base metal.



6) Connect the Earth Clamp securely to the work piece or the work bench.




4) Place the electrode into the electrode holder and clamp tight.




5) Strike the electrode against the work piece to create an arc and hold the electrode steady to maintain the arc



6) Hold the electrode slightly above the work maintaining the arc while travelling at an even speed.





7) To finish the weld, break the arc by quickly snapping the electrode away from the work piece.




8) Wait for the weld to cool and carefully chip away the slag to reveal the weld metal below.

MMA (Manual Metal Arc) Welding

One of the most common types of arc welding is manual metal arc welding (MMA) or stick welding. An electric current is used to strike an arc between the base material and a consumable electrode rod or 'stick'. The electrode rod is made of a material that is compatible with the base material being welded and is covered with a flux that gives off gaseous vapours that serve as a shielding gas and providing a layer of slag, both of which protect the weld area from atmospheric contamination. The electrode core itself acts as filler material the residue from the flux that forms a slag covering over the weld metal must be chipped away after welding.



- The arc is initiated by momentarily touching the electrode to the base metal.
- The heat of the arc melts the surface of the base metal to form a molten pool at the end of the electrode.
- The melted electrode metal is transferred across the arc into the molten pool and becomes the deposited weld metal.
- The deposit is covered and protected by a slag which comes from the electrode coating.
- The arc and the immediate area are enveloped by an atmosphere of protective gas




Manual metal arc (stick) electrodes have a solid metal wire core and a flux coating. These electrodes are identified by the wire diameter and by a series of letters and numbers. The letters and numbers identify the metal alloy and the intended use of the electrode.

The **Metal Wire Core** works as conductor of the current that maintains the arc. The core wire melts and is deposited into the welding pool.

The covering on a shielded metal arc welding electrode is called **Flux**. The flux on the electrode performs many different functions. These include:

- producing a protective gas around the weld area
- providing fluxing elements and deoxidizers
- creating a protective slag coating over the weld as it cools
- establishing arc characteristics
- adding alloying elements.

Covered electrodes serve many purposes in addition to adding filler metal to the molten pool. These additional functions are provided mainly by the covering on the electrode.



MMA (Stick) Welding Fundamentals

Electrode Selection

As a general rule, the selection of an electrode is straight forward, in that it is only a matter of selecting an electrode of similar composition to the parent metal. However, for some metals there is a choice of several electrodes, each of which has particular properties to suit specific classes of work. It is recommended to consult your welding supplier for the correct selection of electrode.

Electrode Size

Average Thickness of Material	Maximum Recommended Electrode Diameter
1.0 - 2.0mm	2.5mm
2.0 - 5.0mm	3.2mm
5.0 - 8.0mm	4.0mm
8.0 - > mm	5.0mm

The size of the electrode generally depends on the thickness of the section being welded, and the thicker the section the larger the electrode required. The table gives the maximum size of electrodes that may be used for various thicknesses of section based on using a general purpose type 6013 electrode.

Welding Current (Amperage)

Electrode Size ø mm	Current Range (Amps)
2.5mm	60 - 95
3.2mm	100 - 130
4.0mm	130 - 165
5.0mm	165 - 260

Correct current selection for a particular job is an important factor in arc welding. With the current set too low, difficulty is experienced in striking and maintaining a stable arc. The electrode tends to stick to the work, penetration is poor and beads with a distinct rounded profile will be deposited. Too high current is accompanied by overheating of the electrode resulting in undercut and burning through of the base metal and producing

excessive spatter. Normal current for a particular job may be considered as the maximum, which can be used without burning through the work, overheating the electrode or producing a rough spattered surface. The table shows current ranges generally recommended for a general purpose type 6013 electrode.

Arc Length

To strike the arc, the electrode should be gently scraped on the work until the arc is established. There is a simple rule for the proper arc length; it should be the shortest arc that gives a good surface to the weld. An arc too long reduces penetration, produces spatter and gives a rough surface finish to the weld. An excessively short arc will cause sticking of the electrode and result in poor quality welds. General rule of thumb for down hand welding is to have an arc length no greater than the diameter of the core wire.

Electrode Angle

The angle that the electrode makes with the work is important to ensure a smooth, even transfer of metal. When welding in down hand, fillet, horizontal or overhead the angle of the electrode is generally between 5 and 15 degrees towards the direction of travel. When vertical up welding the angle of the electrode should be between 80 and 90 degrees to the work piece.

Travel Speed

The electrode should be moved along in the direction of the joint being welded at a speed that will give the size of run required. At the same time, the electrode is fed downwards to keep the correct arc length at all times. Excessive travel speeds lead to poor fusion, lack of penetration etc, while too slow a rate of travel will frequently lead to arc instability, slag inclusions and poor mechanical properties.

Material and Joint Preparation

The material to be welded should be clean and free of any moisture, paint, oil, grease, mill scale, rust or any other material that will hinder the arc and contaminate the weld material. Joint preparation will depend on the method used include sawing, punching, shearing, machining, flame cutting and others. In all cases edges should be clean and free of any contaminants. The type of joint will be determined by the chosen application.

- (1) Turn on the machine using the **ON/OFF** switch
- (2) Select the **TIG** function with the **TIG/MMA** selector switch
- (3) Connect the **Tig Torch** connector to the **negative terminal** and tighten it
- (4) Connect the **Earth Cable** connector into the **positive terminal** and tighten it
- (5) Connect the torch switch remote lead into the torch remote socket
- (6) Insert the torch gas connector into the quick lock gas receptacle
- (7) Connect gas line to Gas Regulator and connect the gas regulator to the Gas Cylinder
Connect the gas line to the quick lock gas inlet connector at the rear of the machine



HF (high frequency) ignition allows the arc to be started in Tig welding without touching the tungsten to the work piece. By pressing the torch switch the machine will activate the gas flow and the HF ignition resulting in the arc igniting across the gap between the tungsten electrode and the work piece. The distance between the electrode and the work piece can be up to 5mm. This arc ignition method prevents tungsten inclusion in the work piece, promotes longer tungsten life and offers better operator control over the starting and stopping the arc.

- (1) Assemble the front end torch parts use the correct size and type of tungsten electrode for the job, the tungsten electrode requires a sharpened point for DC welding.
- (2) Select **DC TIG**, choose **Pulse/No Pulse** and **2T** or **4T** trigger function preferred as per the descriptions below
 - 2T** Selection provides 2 times function of the torch switch.
 - (1) Pressing the torch switch gives arc ignition and initializes the welding current and the welding current is maintained by the torch remaining on.
 - (2) Releasing the torch switch stops the welding by introducing down slope and the current falls to minimum level and then terminates the welding current and introduces the post flow gas.
 - 4T** Selection provides 4 times function of the torch switch
 - (1) Pressing the torch switch gives arc ignition and initializes the welding current
 - (2) Releasing the torch switch continues the welding operation.
 - (3) Pressing the torch switch and holding introduces down slope and current falls to minimum current.
 - (4) Releasing the torch switch terminates the welding operation and introduces the post flow gas.
- (3) Choose the preferred welding current (amperage) to suit the tungsten size material type and thickness to be welded. Set the downslope time and post flow gas time as required.
- (4) Lay the outside edge of the Gas Cup on the work piece with the Tungsten Electrode 1- 3mm from the work piece this method will provide a clean positive arc ignition.
- (5) Press the torch switch and the arc will ignite across the gap between the tungsten and work piece. Hold even distance of about 2mm gap between the tungsten and work piece to maintain the arc.
- (6) Release the torch switch to bring in the end of the welding sequence dependant of 2T or 4T trigger function choice.



(1) Assemble the front end torch parts use the correct size and type of tungsten electrode for the job, the tungsten electrode requires a sharpened point for DC welding




(2) Select **DC** Tig Function. Push the **▶** button until the **DC** icon illuminates red. Select **2T** or **4T** trigger function by the pushing the **▶** button to cycle through the trigger options. Select **DC** non pulse or pulse **▶**




(3) Set the amps required by turning the amps adjustment knob. Set the downslope time and post gas time using the appropriate adjustment knobs.



(4) Lay the outside edge of the Gas Cup on the work piece with the Tungsten Electrode 1- 3mm from the work piece





(5) Press the torch switch and the arc will ignite across the gap between the tungsten and work piece. Hold even distance of about 2mm gap between the tungsten and work piece to maintain the arc.



(6) Release the torch switch to bring in the end of the welding sequence dependant of 2T or 4T trigger function choice


DC TIG Welding - HF Ignition

The DC power source uses what is known as DC (direct current) in which the main electrical component known as electrons flow in only one direction from the negative pole (terminal) to the positive pole (terminal). In the DC electrical circuit there is an electrical principle at work which should always be taken into account when using any DC circuit. With a DC circuit 70% of the energy (heat) is always on the positive side. This needs to be understood because it determines what terminal the TIG torch will be connected to (this rule applies to all the other forms of DC welding as well).




DC TIG welding is a process in which an arc is struck between a Tungsten electrode and the metal work piece. The weld area is shielded by an inert gas flow to prevent contamination of the tungsten, molten pool and weld area.

When the TIG arc is struck the inert gas is ionized and superheated changing its molecular structure which converts it into a plasma stream. This plasma stream flowing between the tungsten and the work piece is the TIG arc and can be as hot as 19,000°C. It is a very pure and concentrated arc which provides the controlled melting of most metals into a weld pool. TIG welding offers the user the greatest amount of flexibility to weld the widest range of material and thickness and types. DC TIG welding is also the cleanest weld with no sparks or spatter.




The intensity of the arc is proportional to the current that flows from the tungsten. The welder regulates the welding current to adjust the power of the arc. Typically thin material requires a less powerful arc with less heat to melt the material so less current (amps) is required, thicker material requires a more powerful arc with more heat so more current (amps) are necessary to melt the material.



HF ARC IGNITION for TIG (tungsten inert gas) Welding

HF (high frequency) ignition allows the arc to be started in Tig welding without touching the tungsten to the work piece. By pressing the torch switch the machine will activate the gas flow and introduce the HF (high frequency) (high voltage) spark, this "ionizes" the air gap making it conductive allowing an arc to be created without touching the tungsten to the work piece. The gas molecules are superheated by the arc creating a stream of super heated gas that changes the molecular structure into producing a plasma stream. This plasma stream provides heat and energy that allows us to melt and fuse metals in an inert gas shielded environment know as TIG (tungsten inert gas) welding.



DC Pulse TIG Welding

Pulse TIG welding is when the current output (amperage) changes between high and low current. Electronics within the welding machine create the pulse cycle. Welding is done during the high-amperage interval (this high amperage is referred to as peak current). During the low amperage period, the arc is maintained but the current output of the arc is reduced (this low amperage is referred to as base current). During pulse welding the weld pool cools during the low amperage period. This allows a lower overall heat input into the base metal. It allows for controlled heating and cooling periods during welding providing better control of heat input, weld penetration, operator control and weld appearance.

There are 4 variables within the pulse cycle:

Peak Current - Base Current - Pulse Frequency - Pulse Width


Setting and manipulation of these variables will determine the nature of the weld current output and is at the discretion of the operator.

Peak Current is the main welding current (amps) set to melt the material being welded and works much the same as setting maximum amperage values for regular DC TIG: as a guide use 30-40 amps for every 1mm of material thickness.


Base Current is the set level of background current (amps) which cools the weld puddle and affects overall heat input. Background Amps is a percentage of peak amperage. As a rule, use enough background current to reduce the weld pool to about half its normal size while still keeping the weld pool fluid. As a guide start by setting the background amperage at 20 to 30 percent of peak amperage.

Pulse Frequency is the control of the amount of times per second (Hz) that the welding current switches from Peak Current to Base Current. DC Pulse TIG frequency generally ranges from 20 to 300 HZ depending on the job application. Control of the pulse frequency also determines the appearance of the weld.

Pulse Width is the control of the percentage of time during one pulsing cycle the power source spends at the peak current (main amperage). Example is with the Pulse Width set at 80 percent and a rate of 1 pulse per second (PPS), the machine will spend 80% of the pulse at peak amperage and 20% at the base current. Increasing the pulse width percentage adds more heat to the job, while decreasing pulse width percentage reduces heat



DC Pulse Tig welding allows faster welding speeds with better control of the heat input to the job, reducing the heat input minimising distortion and warping of the work and is of particular advantage in the welding of thin stainless steel and carbon steel applications. The high pulse frequency capability of the advanced inverter agitates the weld puddle and allows you to move quickly without transferring too much heat to the surrounding metal. Pulsing also constricts and focuses the arc thus increasing arc stability, penetration and travel speeds.




The VIPERTIG 200P machine has digital pulse frequency control. The Peak Amp and Pulse Frequency time are adjustable, where as the Base Amp and Pulse Width are preset for ease of use.

EXAMPLE OF PULSE DC TIG WELDING - SETUP PARAMETERS:


Material = Stainless Steel x 2.0mm / Tungsten Electrode = 1.6mm E3 Tungsten / Gas = Argon

The following steps are a guide as a starting point for you to set the machine up in Pulse mode to give an example of welding in Pulse mode function. You can experiment by changing any of the variables to see what effect it has over the welding and what the end result can be, but it is suggested to change only one variable at a time and then check the welding to see what the result is, in this way you acquire a better understanding of how each variable affects the welding current.




Setting the Pulse Amps

4. The Peak Amps are now set at 100. Because the Base Amp is preset in the machine at 40% it means that the Base Amps will be 40Amps. So the machine now will deliver a cycle of 100Amps - 40 Amps



Setting the Pulse Width

5. The Pulse width is also preset inside the machine for ease of use. Pulse width is the amount of time the peak amp is on during the pulse cycle. The machine is preset at 60% pulse width time. In this case it means the machine will deliver 100amps for 60% of the time and 40amps for 40% of the time during each pulse cycle.




Setting the Pulse Frequency




2. Select the Pulse Frequency using the Pulse Hz Knob.



3. Rotate the Adjustment Knob to set the Pulse Frequency 2 Hz. This means the amperage will cycle from 100 amps to 40amps 2 twice per second. (Range is 0.2 - 200Hz)




TIG Welding Fusion Technique




Manual TIG welding is often considered the most difficult of all the welding processes. Because the welder must maintain a short arc length, great care and skill are required to prevent contact between the electrode and the workpiece. Similar to Oxygen Acetylene torch welding, Tig welding normally requires two hands and in most instances requires the welder to manually feed a filler wire into the weld pool with one hand while manipulating the welding torch in the other. However, some welds combining thin materials can be accomplished without filler metal like edge, corner, and butt joints.


This is known as Fusion welding where the edges of the metal pieces are melted together using only the heat and arc force generated by the TIG arc. Once the arc is started the torch tungsten is held in place until a weld pool is created, a circular movement of the tungsten will assist in creating a weld pool of the desired size. Once the weld pool is established tilt the torch at about a 75° angle and move smoothly and evenly along the joint while fusing the materials together.



Form a weld pool




Angle torch




Move the torch slowly and evenly forward

TIG Welding with Filler Wire Technique




It is necessary in many situations with TIG welding to add a filler wire into the weld pool to build up weld reinforcement and create a strong weld. Once the arc is started the torch tungsten is held in place until a weld pool is created, a circular movement of the tungsten will assist in creating a weld pool of the desired size. Once the weld pool is established tilt the torch at about a 75° angle and move smoothly and evenly along the joint. The filler metal is introduced to the leading edge of the weld pool. The filler wire is usually held at about a 15° angle and fed into the leading edge of the molten pool, the arc will melt the filler wire into the weld pool as the torch is moved forward.


Also a dabbing technique can be used to control the amount of filler wire added, the wire is fed into the molten pool and retracted in a repeating sequence as the torch is moved slowly and evenly forward. It is important during the welding to keep the molten end of the filler wire inside the gas shield as this protects the end of the wire from being oxidised and contaminating the weld pool.




Form a weld pool




Angle torch




Add Tig filler wire



Retract the filler wire



Move the torch forward to the front of the weld pool



Repeat the process


Remote Amperage Controls - Installation and Operation

Remote amperage controls allow for the welding current to be adjusted remotely from the welding machine during welding. Generally there are several types of remote amperage control available;


- (1) Hand amperage control located in the torch handle allowing the operator to adjust the welding current by rolling the potentiometer wheel to increase or decrease the amount of amperage desired.
- (2) Foot amperage control that is a foot pedal that allows the operator to adjust the welding current by depressing the pedal to increase the amperage desired and releasing the pedal to decrease.
- (3) Box amperage control that is a small box housing a potentiometer with a knob that the operator can adjust the welding current turning the knob to increase or decrease the amount of amperage desired.




Connection and operation of the remote hand control



- (1) Push the Pad to select the Remote icon




- (2) Connect the remote control 7 pin plug from the Tig Torch switch lead to the 7 pin remote receptacle on the front panel of the machine.




- (3) Press the switch to activate the machine. Rotate the amp control potentiometer to select the desired welding current.

Connection and operation of the remote foot control



- (1) Push the Pad to select the Remote icon



- (2) Connect the remote control 7 pin plug from the Tig Torch switch lead to the 7 pin remote receptacle on the front panel of the machine.



- (3) Set the dial on the foot control to the desired setting eg - Max = Maximum current output, 50% = 50% of the maximum current output of the machine. Depress the foot pedal to activate the machine, further depressing the pedal will increase the current level to the maximum set by the dial on the foot control.

Tungsten Electrodes

Tungsten is a rare metallic element used for manufacturing TIG welding electrodes. The TIG process relies on tungsten's hardness and high-temperature resistance to carry the welding current to the arc. Tungsten has the highest melting point of any metal, 3,410 degrees Celsius. Tungsten electrodes are nonconsumable and come in a variety of sizes, they are made from pure tungsten or an alloy of tungsten and other rare earth elements. Choosing the correct tungsten depends on the material being welded, amps required and whether you are using AC or DC welding current. Tungsten electrodes are colour-coded at the end for easy identification. Below are the most commonly used tungsten electrodes found in the New Zealand and Australian market.

Thoriated

Thoriated tungsten electrodes (AWS classification EWTh-2) contain a minimum of 97.30 percent tungsten and 1.70 to 2.20 percent thorium and are called 2 percent thoriated. They are the most commonly used electrodes today and are preferred for their longevity and ease of use. Thorium however is a low-level radioactive hazard and many users have switched to other alternatives. Regarding the radioactivity, thorium is an alpha emitter but when it is enclosed in a tungsten matrix the risks are negligible. Thoriated tungsten should not get in contact with open cuts or wounds. The more significant danger to welders can occur when thorium oxide gets into the lungs. This can happen from the exposure to vapours during welding or from ingestion of material/dust in the grinding of the tungsten. Follow the manufacturer's warnings, instructions, and the Material Safety Data Sheet (MSDS) for its use.

E3 (Color Code: Purple)

E3 tungsten electrodes (AWS classification EWG) contain a minimum of 98% percent tungsten and up to 1.5 percent Lanthanum and small percentages of Zirconium and Yttrium they are called E3 Tungsten. E3 Tungsten Electrodes provide conductivity similar to that of thoriated electrodes. Typically, this means that E3 Tungsten Electrodes are exchangeable with thoriated electrodes without requiring significant welding process changes. E3 deliver superior arc starting, electrode lifetime, and overall cost-effectiveness. When E3 Tungsten Electrodes are compared with 2% thoriated tungsten, E3 requires fewer re-grinds and provides a longer overall lifetime. Tests have shown that ignition delay with E3 Tungsten Electrodes actually improves over time, while 2% thoriated tungsten starts to deteriorate after only 25 starts. At equivalent energy output, E3 Tungsten Electrodes run cooler than 2% thoriated tungsten, thereby extending overall tip lifetime. E3 Tungsten Electrodes work well on AC or DC. They can be used DC electrode positive or negative with a pointed end, or balled for use with AC power sources.

Ceriated (Color Code: Orange)

Ceriated tungsten electrodes (AWS classification EWCe-2) contain a minimum of 97.30 percent tungsten and 1.80 to 2.20 percent cerium and are referred to as 2 percent ceriated. Ceriated tungstens perform best in DC welding at low current settings. They have excellent arc starts at low amperages and become popular in such applications as orbital tube welding, thin sheet metal work. They are best used to weld carbon steel, stainless steel, nickel alloys, and titanium, and in some cases it can replace 2 percent thoriated electrodes. Ceriated tungsten is best suited for lower amperages it should last longer than Thoriated tungsten higher amperage applications are best left to Thoriated or Lanthanated tungsten.

Lanthanated (Color Code: Gold)

Lanthanated tungsten electrodes (AWS classification EWL-1.5) contain a minimum of 97.80 percent tungsten and 1.30 percent to 1.70 percent lanthanum, and are known as 1.5 percent lanthanated. These electrodes have excellent arc starting, a low burn off rate, good arc stability, and excellent re-ignition characteristics. Lanthanated tungstens also share the conductivity characteristics of 2 percent thoriated tungsten. Lanthanated tungsten electrodes are ideal if you want to optimise your welding capabilities. They work well on AC or DC electrode negative with a pointed end, or they can be balled for use with AC sine wave power sources. Lanthanated tungsten maintains a sharpened point well, which is an advantage for welding steel and stainless steel on DC or AC from square wave power sources.

Zirconiated (Color Code: White)

Zirconiated tungsten electrodes (AWS classification EWZr-1) contain a minimum of 99.10 percent tungsten and 0.15 to 0.40 percent zirconium. Most commonly used for AC welding Zirconiated tungsten produces a very stable arc and is resistant to tungsten spitting. It is ideal for AC welding because it retains a balled tip and has a high resistance to contamination. Its current-carrying capacity is equal to or greater than that of thoriated tungsten. Zirconiated tungsten is not recommended for DC welding.

Tungsten Electrodes Rating for Welding Currents

Tungsten Diameter mm	DC Current Amps Torch Negative 2% Thoriated	AC Current Amps Un-Balanced Wave 0.8% Zirconiated	AC Current Amps Balanced Wave 0.8% Zirconiated
1.0mm	15 - 80	15 - 80	20 - 60
1.6mm	70 - 150	70 - 150	60 - 120
2.4mm	150 - 250	140 - 235	100 - 180
3.2mm	250 - 400	225 - 325	160 - 250
4.0mm	400 - 500	300 - 400	200 - 320

Tungsten Electrode Preparation

Always use **DIAMOND** wheels when grinding and cutting. While tungsten is a very hard material, the surface of a diamond wheel is harder, and this makes for smooth grinding. Grinding without diamond wheels, such as aluminium oxide wheels, can lead to jagged edges, imperfections, or poor surface finishes not visible to the eye that will contribute to weld inconsistency and weld defects.

Always ensure to grind the tungsten in a longitudinal direction on the grinding wheel. Tungsten electrodes are manufactured with the molecular structure of the grain running lengthwise and thus grinding crosswise is “grinding against the grain.” If electrodes are ground crosswise, the electrons have to jump across the grinding marks and the arc can start before the tip and wander. Grinding longitudinally with the grain, the electrons flow steadily and easily to the end of the tungsten tip. The arc starts straight and remains narrow, concentrated, and stable.



Electrode Tip/Flat


The shape of the tungsten electrode tip is an important process variable in precision arc welding. A good selection of tip/flat size will balance the need for several advantages. The bigger the flat, the more likely arc wander will occur and the more difficult it will be to arc start. However, increasing the flat to the maximum level that still allows arc start and eliminates arc wander will improve the weld penetration and increase the electrode life. Some welders still grind electrodes to a sharp point, which makes arc starting easier. However, they risk decreased welding performance from melting at the tip and the possibility of the point falling off into the weld pool.



Electrode Included Angle/Taper - DC Welding

Tungsten electrodes for DC welding should be ground longitudinally and concentrically with diamond wheels to a specific included angle in conjunction with the tip/flat preparation. Different angles produce different arc shapes and offer different weld penetration capabilities. In general, blunter electrodes that have a larger included angle provide the following benefits:

- Last Longer
- Have better weld penetration
- Have a narrower arc shape
- Can handle more amperage without eroding.



Sharper electrodes with smaller included angle provide:

- Offer less arc weld
- Have a wider arc
- Have a more consistent arc



The included angle determines weld bead shape and size. Generally, as the included angle increases, penetration increases and bead width decreases.

Tungsten Diameter	Diameter at the Tip - mm	Constant Included Angle - Degrees	Current Range Amps	Current Range Pulsed Amps
1.0mm	.250	20	05 - 30	05 - 60
1.6mm	.500	25	08 - 50	05 - 100
1.6mm	.800	30	10 - 70	10 - 140
2.4mm	.800	35	12 - 90	12 - 180
2.4mm	1.100	45	15 - 150	15 - 250
3.2mm	1.100	60	20 - 200	20 - 300
3.2mm	1.500	90	25 - 250	25 - 350

TIG WELDING TORCHES

XA17 Suregrip TIG Torch 150 Amp

Air Cooled 150 Amp - Available in 4m, 8m Lengths




XA17 TIG TORCH

Suregrip Series

150AMP AIR COOLED

Rating: 150A DC, 105A AC @35% duty cycle.



* Wear Parts Identification Next Page

Torch Model	Description	Part Number	
		4m	8m
XA17 Suregrip Tig Torch 4m, Surelok Connector QF Gas		XA17-S112GS4	XA17-S125GS4
XA17FX Suregrip Flexi Tig Torch 4m, Surelok Connector QF Gas		XA17FX-S112GS4	XA17FX-S125GS4

Spare Parts		
Part Number	Description	
1	XA17 XA17FX	Torch Body Standard Torch Body Flexible
2	57Y02	Back Cap Long
2a	98W18	Back Cap O Ring
3	P300M	Back Cap Medium
4	57Y04	Back Cap Short
5	ER1MS	Momentary Switch Kit
6	ERSWL4 ERSWL8	Trigger Lead x 4m Trigger Lead x 8m
7	ERSP1	Screw Pack
8	ERH100	Small Ergo Tig Handle
9	ERKJ100	Small Knuckle Joint
10	ERLC100-08	Leather Cover x 0.8m

Spare Parts		
Part Number	Description	
11	ERJK100	Jointing Repair Kit
12	ERNCL-32 ERNCL-72	Neoprene Cover Sheath x 3.2m Neoprene Cover Sheath x 7.2m
13	ERCO100-40 ERCO100-80	Sheath x 4m c/w Leather Cover Sheath x 8m c/w Leather Cover
14	SLH917-S	Cable Support Small
15	SLH917-H	Surelok Housing Small
16	SL57Y01AR SL57Y03AR	Power Cable x 4m Surelok Rubber Power Cable x 8m Surelok Rubber
17	SL3550 SL2510	Surelok Body & Support 35-50 Surelok Body & Support 16-25
18	SL-1-WR3	Gas Supply Hose
19	10004667	7 Pin Plug

TIG WELDING TORCHES

XA17 Suregrip TIG Torch 150 Amp

Torch Head Parts - Collets, Collet Bodies, Gas Lens, Gaskets, Nozzles



Standard Front End Parts


Part #	Description
18CG	Cup Gasket



Part #	Description
10N22	Collet 1.0mm
10N23	Collet 1.6mm
10N24	Collet 2.4mm
10N25	Collet 3.2mm



Part #	Description
10N30	Collet Body 1.0mm
10N31	Collet Body 1.6mm
10N32	Collet Body 2.4mm
10N28	Collet Body 3.2mm



Part #	Description
10N50	Alumina Nozzle Ø 6mm #4
10N49	Alumina Nozzle Ø 8mm #5
10N48	Alumina Nozzle Ø 10mm #6
10N47	Alumina Nozzle Ø 11mm #7
10N46	Alumina Nozzle Ø 13mm #8
10N45	Alumina Nozzle Ø 16mm #10
10N44	Alumina Nozzle Ø 19mm #12



Part #	Description
10N49L	Long Alumina Nozzle Ø 8mm #5L
10N48L	Long Alumina Nozzle Ø 10mm #6L
10N47L	Long Alumina Nozzle Ø 11mm #7L



Gas Lens Front End Parts


Part #	Description
18CG	Cup Gasket
54N01	Gas Lens Gasket



Part #	Description
10N22	Collet 1.0mm
10N23	Collet 1.6mm
10N24	Collet 2.4mm
10N25	Collet 3.2mm




Part #	Description
45V24	Gas Lens Collet Body 1.0mm
45V25	Gas Lens Collet Body 1.6mm
45V26	Gas Lens Collet Body 2.4mm
45V27	Gas Lens Collet Body 3.2mm



Part #	Description
54N18	Gas Lens Nozzle Ø 6mm #4
54N17	Gas Lens Nozzle Ø 8mm #5
54N16	Gas Lens Nozzle Ø 10mm #6
54N15	Gas Lens Nozzle Ø 11mm #7
54N14	Gas Lens Nozzle Ø 12mm #8
54N19	Gas Lens Nozzle Ø 16mm #11




Part #	Description
54N17L	Long Gas Lens Nozzle Ø 8mm #5L
54N16L	Long Gas Lens Nozzle Ø 10mm #6L
54N15L	Long Gas Lens Nozzle Ø 11mm #7L



Large Gas Lens Front End Parts


Part #	Description
18CG	Cup Gasket
54N63	Large Lens Gasket



Part #	Description
10N22	Collet 1.0mm
10N23	Collet 1.6mm
10N24	Collet 2.4mm
10N25	Collet 3.2mm



Part #	Description
45V0204	Large Gas Lens Body 1.0mm
45V116	Large Gas Lens Body 1.6mm
45V64	Large Gas Lens Body 2.4mm
995795	Large Gas Lens Body 3.2mm



Part #	Description
57N75	Large Gas Lens Nozzle Ø 10mm #6
57N74	Large Gas Lens Nozzle Ø 12mm #8
53N88	Large Gas Lens Nozzle Ø 16mm #10
53N87	Large Gas Lens Nozzle Ø 19mm #12



Stubby Front End Parts


Part #	Description
18CG20	Stubby Cup Gasket



Part #	Description
10N22S	Stubby Collet 1.0mm
10N23S	Stubby Collet 1.6mm
10N24S	Stubby Collet 2.4mm
10N25S	Stubby Collet 3.2mm



Part #	Description
17CB20	Stubby Collet Body Fits 1.0 - 3.2mm



Part #	Description
13N08	Alumina Nozzle Ø 6mm #4
13N09	Alumina Nozzle Ø 8mm #5
13N10	Alumina Nozzle Ø 10mm #6
13N11	Alumina Nozzle Ø 11mm #7
13N12	Alumina Nozzle Ø 13mm #8
13N13	Alumina Nozzle Ø 16mm #10



Part #	Description
796F70	Long Alumina Nozzle Ø 4mm #3
796F71	Long Alumina Nozzle Ø 6mm #4
796F72	Long Alumina Nozzle Ø 8mm #5
796F73	Long Alumina Nozzle Ø 10mm #6



Stubby Gas Lens Front End Parts

Part #	Description
80300236	Gas Lens Gasket



Part #	Description
10N23S	Stubby Collet 1.6mm
10N24S	Stubby Collet 2.4mm
10N25S	Stubby Collet 3.2mm



Part #	Description
USTB45V43	Stubby Gas Lens Body 1.6mm
USTB45V44	Stubby Gas Lens Body 2.4mm
USTB45V45	Stubby Gas Lens Body 3.2mm



Part #	Description
53N58	Gas Lens Nozzle Ø 6mm #4
53N59	Gas Lens Nozzle Ø 8mm #5
53N60	Gas Lens Nozzle Ø 10mm #6
53N61	Gas Lens Nozzle Ø 11mm #7
53N61S	Gas Lens Nozzle Ø 15mm #8



The RedNeck Contractors Kit allows you to easily convert your existing standard air cooled TIG Torch to the RedNeck System. The unique RedNeck Flexible Neck Coil provides incredible directional control of the torch head, allowing you to place your torch head in almost any position & giving you precise control over your TIG welds even in the most difficult out of position welds. The RedNeck Flexible Neck Coil has been rigorously tested and proven to be over 20 times more durable than conventional flexible TIG Torch necks



RedNeck Contractors Kit

The RedNeck Torch Body & Flexible Neck Coil simply connects to your existing air cooled TIG Torch cable. Interchangeable angled Torch Heads simply screw on & off the Flexible Neck Coil. Each kit is supplied with compact Gas Lens parts for 1.6 & 2.4mm Tungstens. RedNeck is ideal for the Stainless Steel Contractor and those looking for superior weld control with outstanding weld finish & appearance. All parts are available separately.

Part #		Description		RedNeck			
Part #	RN-18H-180	Description	180° TIG Torch Head w/gasket	RNK-17-150 CONTRACTORS KIT SPARE PARTS LISTING			
				Part #	45V25S	Description	SW Stubby Gas Lens Body 1.6mm
Part #	RN-18H-90	Description	90° TIG Torch Head w/gasket				
				Part #	45V26S	Description	SW Stubby Gas Lens Body 2.4mm
Part #	RN-18H-70	Description	70° TIG Torch Head w/gasket				
				Part #	10N23S	Description	Stubby Collet 1.6mm
				Part #	10N24S	Description	Stubby Collet 2.4mm
				Part #	54N15SW	Description	GL Alumina Nozzle 11.0mm Short
				Part #	54N14SW	Description	GL Alumina Nozzle 12.5mm Short
				Part #	54N12SW	Description	GL Alumina Nozzle 16.0mm Short

MMA (Stick) Welding Trouble Shooting

The following chart addresses some of the common problems of MMA welding. In all cases of equipment malfunction, the manufacturer's recommendations should be strictly adhered to and followed.

1: No arc	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Incomplete welding circuit	Check earth lead is connected. Check all cable connections.
Wrong mode selected	Check the MMA selector switch is selected
No power supply	Check that the machine is switched on and has a power supply
2: Porosity – small cavities or holes resulting from gas pockets in weld metal.	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Arc length too long	Shorten the arc length
Work piece dirty, contaminated or moisture	Remove moisture and materials like paint, grease, oil, and dirt, including mill scale from base metal
Damp electrodes	Use only dry electrodes
3: Excessive Spatter	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Amperage too high	Decrease the amperage or choose a larger electrode
Arc length too long	Shorten the arc length
3: Weld sits on top, lack of fusion	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Insufficient heat input	Increase the amperage or choose a larger electrode
Work piece dirty, contaminated or moisture	Remove moisture and materials like paint, grease, oil, and dirt, including mill scale from base metal
Poor welding technique	Use the correct welding technique or seek assistance for the correct technique
4: Lack of penetration	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Insufficient heat input	Increase the amperage or choose a larger electrode
Poor welding technique	Use the correct welding technique or seek assistance for the correct technique
Poor joint preparation	Check the joint design and fit up, make sure the material is not too thick. Seek assistance for the correct joint design and fit up
5: Excessive penetration - burn through	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Excessive heat input	Reduce the amperage or use a smaller electrode
Incorrect travel speed	Try increasing the weld travel speed
6: Uneven weld appearance	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Unsteady hand, wavering hand	Use two hands where possible to steady up, practise your technique
7: Distortion – movement of base metal during welding	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Excessive heat input	Reduce the amperage or use a smaller electrode
Poor welding technique	Use the correct welding technique or seek assistance for the correct technique
Poor joint preparation and or joint design	Check the joint design and fit up, make sure the material is not too thick. Seek assistance for the correct joint design and fit up
7: Electrode welds with different or unusual arc characteristic	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Incorrect polarity	Change the polarity, check the electrode manufacturer for correct polarity

TIG Welding Trouble Shooting

The following chart addresses some of the common problems of DC TIG welding. In all cases of equipment malfunction, the manufacturer's recommendations should be strictly adhered to and followed.

1: Tungsten burning away quickly	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Incorrect Gas	Check that pure Argon is being used
No gas	Check the gas cylinder contains gas and is connected and the torch gas valve is open
Inadequate gas flow	Check the gas is connected, check hoses, gas valve and torch are not restricted. Set the gas flow between 10 - 15 l/min flow rate
Back cap not fitted correctly	Make sure the torch back cap is fitted so that the o-ring is inside the torch body
Torch connected to DC +	Connect the torch to the DC- output terminal
Incorrect tungsten being used	Check and change the tungsten type if necessary
Tungsten being oxidised after weld is finished	Keep shielding gas flowing 10–15 seconds after arc stoppage. 1 second for each 10 amps of weld current.
2: Contaminated tungsten	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Touching tungsten into the weld pool	Keep tungsten from contacting weld puddle. Raise the torch so that the tungsten is off of the work piece 2 - 5mm
Touching the filler wire to the tungsten	Keep the filler wire from touching the tungsten during welding, feed the filler wire into the leading edge of the weld pool in front of the tungsten
Tungsten melting into the weld pool	Check that correct type of tungsten is being used. Too much current for the tungsten size so reduce the amps or change to a larger tungsten
3: Porosity - poor weld appearance and colour	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Incorrect Gas	Check that pure Argon is being used
Inadequate gas flow / gas leaks	Check the gas is connected, check hoses, gas valve and torch are not restricted. Set the gas flow between 10 - 15 l/min flow rate. Check hoses and fittings for holes, leaks etc.,
Moisture on the base metal	Remove all moisture from base metal before welding
Contaminated base metal	Remove materials like paint, grease, oil, and dirt, including mill scale from base metal
Contaminated filler wire	Remove all grease, oil, or moisture from filler metal.
Incorrect filler wire	Check the filler wire and change if necessary
4: Yellowish residue / smoke on the alumina nozzle & discoloured tungsten	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Incorrect Gas	Use pure Argon gas
Inadequate gas flow	Set the gas flow between 10 - 15 l/min flow rate
Alumina gas nozzle too small for size of tungsten being used	Increase the size of the alumina gas nozzle
5: Unstable Arc during DC welding	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Torch connected to DC +	Connect the torch to the DC- output terminal
Contaminated base metal	Remove materials like paint, grease, oil, and dirt, including mill scale from base metal.
Tungsten is contaminated	Remove 10mm of contaminated tungsten and re grind the tungsten
Arc length too long	Lower torch so that the tungsten is off of the work piece 2 - 5mm
7: Arc wanders during DC welding	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Poor gas flow	Check and set the gas flow between 10 - 15 l/min flow rate
Incorrect arc length	Lower torch so that the tungsten is off of the work piece 2 - 5mm
Tungsten incorrect or in poor condition	Check that correct type of tungsten is being used. Remove 10mm from the weld end of the tungsten and re sharpen the tungsten
Poorly prepared tungsten	Grind marks should run lengthwise with tungsten, not circular. Use proper grinding method and wheel.
Contaminated base metal	Remove contaminating materials like paint, grease, oil, and dirt, including mill scale from base metal.
Contaminated filler wire	Remove all grease, oil, or moisture from filler metal.
Incorrect filler wire	Check the filler wire and change if necessary

continued- TIG Welding Trouble Shooting

8: Arc difficult to start or will not start DC welding	
<i>Possible Reason</i>	<i>Suggested Remedy</i>
Incorrect machine set up	Check machine set up is correct
No gas, incorrect gas flow	Check the gas is connected and cylinder valve open, check hoses, gas valve and torch are not restricted. Set the gas flow between 10 - 15 l/min flow rate
Tungsten is contaminated	Remove 10mm of contaminated tungsten and re grind the tungsten
Incorrect tungsten size and or tungsten being used	Check and change the size and or the tungsten if required
Loose connection	Check all connectors and tighten
Earth clamp not connected to work	Connect the earth clamp directly to the work piece wherever possible

ATTENTION! - CHECK FOR GAS LEAKS

At initial set up and at regular intervals we recommend to check for gas leakage.

Recommended procedure is as follows:

1. Connect the regulator and gas hose assembly and tighten all connectors and clamps.
2. Slowly open the cylinder valve.
3. Set the flow rate on the regulator to approximately 8-10 l/min.
4. Close the cylinder valve and pay attention to the needle indicator of the contents pressure gauge on the regulator, if the needle drops away towards zero there is a gas leak.
Sometimes a gas leak can be slow and to identify it will require leaving the gas pressure in the regulator and line for an extended time period. In this situation it is recommended to open the cylinder valve, set the flow rate to 8-10 l/min, close the cylinder valve and check after a minimum of 15 minutes.
5. If there is a gas loss then check all connectors and clamps for leakage by brushing or spraying with soapy water, bubbles will appear at the leakage point.
6. Tighten clamps or fittings to eliminate gas leakage.

Important: We strongly recommend that you check for gas leakage prior to operation of your machine. We recommend that you close the cylinder valve when the machine is not in use.

Esseti NZ Ltd, authorised representatives or agents of Esseti NZ Ltd will not be liable or responsible for the loss of any gas.

ESSETI (NZ) LIMITED WARRANTY POLICY

We understand that sometimes you may need to return a product that you have purchased from our Esseti NZ Ltd.

Authorised Distributor Network. To assist you, we have set out below the Esseti NZ Ltd Warranty Returns Policy that you should know about. These terms and conditions supersede and exclude all former and other representations and arrangements relating to any warranties on these products, irrespective of whether expressed or implied.

ESSETI New Zealand Limited ('us', 'we') warrants that the products bearing the brand names ESSETI, XCEL-ARC, RAZORWELD, RAZORCUT, JASIC, VIPER, T&R, XCEL-GAS, Otos, Servore, TECNA & HIT-8SS supplied by us and purchased by you from an Authorised ESSETI (NZ) Ltd. Distributor are free of Material and Faulty Workmanship Defects except for those products listed under 'Warranty Exclusions' and whilst any claim is made subject to the following terms and conditions.

Your rights under the New Zealand Consumer Law may not be limited by a defined time. However, New Zealand Consumer Law does recognise that the relevant time period can vary from product to product, depending on factors such as the nature of the product and the price. Esseti NZ Ltd. adopts the same approach. As you can appreciate, the type of remedy we can offer you may also vary depending on how long it takes you to return the product to us.

WARRANTY PERIOD

We offer the following 'Warranty Periods' effective from the 'date of purchase':

- XCEL-ARC, Inverter MIG/SWF/MTS, MMA/TIG, TIG ACDC, Plasma (Power Source Only*)	2 Years
- RAZORWELD, Inverter MIG/SWF/MTS, MMA/TIG, TIG ACDC (Power Source Only*)	3 Years
- VIPER, Inverter MIG/SWF/MTS, MMA/TIG, TIG ACDC, Plasma (Power Source Only*)	1 Year
- RAZORCUT, Inverter Plasma (Power Source Only*)	2 Years
- JASIC, Inverter MIG/SWF/MTS, MMA/TIG, TIG ACDC, Plasma (Power Source Only*)	2 Years
- XCEL-ARC & RAZORWELD, Water Coolers, PAPR Air Blower Unit	1 Year
- XCEL-GAS, Gas Cutting and Welding Torches	3 Months
- XCEL-GAS, Straight Line & Gas Cutting Machines (Power Source Only*)	1 Year
- XCEL-GAS, Regulators Argon/ Acetylene / Oxygen / LPG / Bobbin Flowmeter	1 Year
- XCEL-ARC, Automatic Welding Helmet	2 Years
- RAZORWELD, Automatic Welding Helmets / Goggles	1 Year
- SERVORE, Automatic Welding Helmets / Goggles	1 Year
- OTOS, Automatic Welding Helmets	2 Years
- TECNA, Spot Welding Machines (Power Source Only*)	1 Year
- HIT-8SS, Automatic Carriage (Power Source Only*)	1 Year
- ALL WELDING TORCHES – GMAW / GTAW / MMAW / PLASMA	3 Months
- ALL EARTH LEADS, INTERCONNECTING CABLES, GAS HOSES	3 Months

(*) This only covers manufacturing faults on any torches, cables and other accessories, either included with a machine kitset or sold separately, for the first three months after date of purchase.

WARRANTY / RETURNS / EXCHANGES

Our Warranty Returns Policy recognises all and any rights you have under New Zealand Consumer Law and other relevant laws.

You shall inspect the goods on delivery and shall within seven (7) days of delivery (time being of the essence) notify the Esseti NZ Ltd. Authorised Distributor from whom you purchased the goods of any alleged defect, shortage in quantity, damage or failure to comply with the description or quote.

You shall also afford Esseti NZ Ltd. the opportunity to inspect the goods within a reasonable time following delivery if you believe the goods are defective in any way.

If you shall fail to comply with these provisions the goods shall be presumed to be free from any defect or damage.

For defective goods and where permissible by law, Esseti NZ Ltd. reserves the right to repair or otherwise remedy the defect prior to issuing replacement goods or refunding the purchase price.

If the goods are being purchased for a business purpose then the purchaser acknowledges that the Consumer Guarantees Act will not apply.

The New Zealand Sales of Goods Act applies when goods are not covered by the Consumer Guarantees Act. You may be able to get a full refund or compensation if the trader doesn't have the right to sell the goods, or the goods are:

- not of 'merchantable quality' (so defective that most people wouldn't want them)
- not fit for their normal purpose
- poorer quality than a sample you were shown
- not suitable for what you told the trader you wanted the goods for
- not matching their description

If there has been a misrepresentation you may have rights under the Fair Trading Act or the Contractual Remedies Act and therefore also entitled to, at the consumer's discretion, either a refund of the purchase price of the goods, or repair of the goods, or replacement of the goods.

Returns will only be accepted provided that:

- You have complied with the provisions outlined above, and
- where the goods are unable to be repaired, the goods are returned at your cost within thirty (30) days of the delivery date, and
- Esseti NZ Ltd. will not be liable for goods which have not been stored or used in a proper manner, and
- the goods are returned in the condition in which they were delivered and with all packaging material, brochures and instructional material in as new condition as is reasonably possible in the circumstances.

Esseti NZ Ltd. Accepts no responsibility for any products lost, damaged or mislaid whilst in transit. Esseti NZ Ltd. may (at their sole discretion) accept the return of goods for credit but this may incur a handling fee of up to fifteen percent (15%) of the value of the returned Goods plus any freight costs.

MAKING A CLAIM

If you wish to make a claim under this Warranty, you should:

- Return the product to the point of purchase either in person or via prepaid courier; or
- Contact us by Telephone - Esseti NZ Ltd, **06 355 1103**

When returned, the product must be accompanied with the original Receipt or Tax Invoice clearly showing the purchase date and disclosing the purchase price. All costs of installation, cartage, freight, travelling expenses, hiring tools and insurance are paid by the Customer. To the extent permitted by law, our total liability for loss or damage of every kind related to the goods in any way whatsoever is limited to the amount paid to the retailer by you for the goods or the value of the goods. No responsibility will be taken for any products lost, damaged or mislaid whilst in transit.

WARRANTY EXCLUSIONS

This Warranty covers Material and Faulty Workmanship defects only. This Warranty does not cover damage caused by:

- Normal wear and tear due to usage
- Misuse or abusive use of the machine and/or failure to correctly follow set up or operating instructions supplied with these products
- Failure to clean or improper cleaning of the product
- Failure to maintain the equipment such as regular services, etc.
- Incorrect voltage or non-authorized electrical connections
- Improper installation
- Use of non-authorized/non-standard parts
- Abnormal product performance caused by any ancillary equipment interference or other external factors
- Failure or any breakage caused by overload, dropping or abusive treatment or use by the customer
- Repair, modifications or other work carried out on the product other than by an Esseti-Authorised Service Agent

Unless it is a manufacturing fault, this Warranty does not cover the following parts:

- **All Batteries, including Button Type and Cell Type Batteries**
- **MIG Welding Torch Consumables, such as:**
Gas Nozzles, Gas Diffusers, Contact Tip Holders, Contact Tips, Swan Necks, Triggers, Handles, Liners, Euro Block, Shroud Springs, Knobs, All XCEL-ARC / Magmaweld Mig Welding Wires & Electrodes, Arc Leads, Welding Cable, Electrode Holder, Earth Clamps
- **MMA & TIG Welding Torch Consumables, such as:**
Tungsten Electrodes, Collet, Collet Body, Alumina Nozzle, Torch Head, Torch Head water Cooled, Torch Head Flexible, Back Caps, Gas Lens, Torch Handle, Cup Gasket, Torch Body Gas Valve, O-ring, All XCEL-ARC TIG Welding Rods, All XCEL-ARC / Magmaweld Electrodes, Arc Leads, Welding Cable, Electrode Holder, Earth Clamps
- **PLASMA Cutting Torches Consumables, such as:**
All Cutting Tips, All Diffuser/Swirl Ring, All Electrodes, Retaining Caps, Nozzle Springs, All Spacers, All Shield Caps, All Air and Power Cables, All Switches, All O-rings, All Springs, All Circle Guides and Cutting Kits, Torch Bodies, Air Filter Regulator, Welding Cable, Earth Clamps
- **Gas Welding & Cutting Torch and Straight Line Cutting Machine Consumables and Fittings, such as:**
All Cutting, Welding & Brazing Tips, Adaptors, Hoses, Fittings, Tracks and associated parts
- **Automatic Welding & Cutting Carriage Machine Parts, such as:**
Input Cord, Inter-connecting Power Cord, Triggering Cable

This Warranty does not cover products purchased:

- Without the provision of a suitable Receipt or Tax Invoice that clearly provides proof of purchase as outlined above
- At an auction or from a private seller
- Unless it is a manufacturing fault, this Warranty does not apply to any products sold to Hire Companies.

These conditions may only be varied with the written approval of the Directors of Esseti NZ Limited.

REMEMBER TO RETAIN YOUR ORIGINAL INVOICE FOR PROOF OF PURCHASE.

